

ASSEMBLY INSTRUCTIONS

i-12 INDOOR



www.knighttablesport.co.uk



Before starting to assemble the table tennis table, or using it for the first time, please read the assembly and operating instructions very carefully. They contain important advice for safety when using the table. Please keep these instructions for information, maintenance or ordering spare parts.



Assembly requires 2 adults during all stages.

All the tools required to complete the assembly are included with the table.


Assembly should be carried out on a clean, dry, soft floor. Please ensure there is nothing on the floor that could scratch the table tops.

Before commencing the assembly, check all parts against the parts list and make sure they are all present and correct.

Please follow the ABC references for the order of the assembly.

If there is a text mark, please read the explanation on page 10.


If there is a part mark, please read the information relating to it in the parts list on page 12.





Set the table up on a level surface.


equipment. In most cases, a damp cloth is sufficient. Specialist cleaning products are available.

































Please repeat these assembly steps with the second table top.




Go back to step D and assemble the second table top.



Upon completion of the assembly, please check all the working parts in accordance with the instructions on page 11. Where applicable please take care when removing the coating from the playing surface.

Table Surface Tolerance




Caution: Follow the instructions carefully when handling the table.

Please fold the table away when your game is over. DO NOT use corrosive or abrasive materials to clean the table. In most cases, a very slightly moist cloth is sufficient. Specialist cleaning products are available. FOR INDOOR USE ONLY.

Open:

Adult supervision is required when folding and unfolding the table.


- A) Lift the handle to release; maintain this action whilst the tabletop is being lowered.
- B) Lower the tabletop into the game position. Do not allow it to fall, as this might cause damage or injury.
- C) For improved safety and a better playing experience check the second locking level is engaged. If not, raise the tabletop from each side of the net until it engages.




Close:

Adult supervision is required when folding and unfolding the table.

- A) Pull the handle under the tabletop to release; maintain this action whilst the tabletop is being lifted.
- B) Lift the tabletop up into its storage position.
- C) For your safety, check that the tabletop is properly locked.



The Guarantee does not cover any damage which occurs as a result of incorrect use.



www.knighttablesport.co.uk e-mail: sales@knighttablesport.co.uk