



KNIGHT TABLE SPORT

i-S12 INDOOR

Please read these instructions carefully before you start to assemble or use this table tennis table. They contain important information relating to safety, assembly and maintenance.

We recommend you keep these instructions for future reference in case you need to order spare parts or carry out any maintenance.

Assembly should be carried out by two adults throughout each stage.

Tools required:



14mm


Preparation for use

1. Open the carton and check to ensure all accessories and fittings are complete.
2. Install 'T' rolling leg according to figure 1 below.
3. Tighten all screws and turn table up the right way ready for use.

Assembly Instructions

Carefully lay both table tops flat and face down on a soft surface. Unlock and unfold pre-assembled table top, slide 'T' rolling leg into designated position and ensure marking tape lines up on each side, see figure 1.

Figure 1




Care and Maintenance

1. Move the two halves slightly away from each other before opening and closing, this will avoid any contact between the tops.
2. Do not use or store the table outside: both direct sunlight and damp conditions can cause the table to warp.
3. Avoid excessive contact of the bat against the table top.
4. Do not place hot goods on table top.
5. Do not sit or place heavy goods on table.
6. Do not use the table for any exercise other than table tennis.
7. Do not move table around quickly on bumpy, rugged ground.
8. Keep the table in a dry, well insulated area after playing.
9. DO NOT use a wet cloth to clean the table. There are specialist cleaning sprays available from most good retailers.

Operation Method

Security Lock Operation




Release the lock before opening the Table Tennis Table and lock it prior to folding the table.

Leg Hinge

When in use

When Collapsing




Straighten hinge when using table and collapse hinge to fold table.

Wheel Operation

Locked

Unlocked



Lock wheel tightly when using table and unlock for moving and storing.

Height Adjusting Method





Figure 5

The wheel height can be adjusted to a maximum of 15mm.

To adjust the table height at wheel, screw part A (as seen in figure 5) anti-clockwise to raise the table, and Part B clockwise to lower it.



The foot height can also be adjusted to a maximum of 15mm.

To adjust table height at the foot, screw foot anti-clockwise to raise the table, and clockwise to lower it.

All feet can be adjusted slightly to ensure a level playing surface.

Note on Safety

- The table tennis table should be used only for its intended purpose. All other uses may be dangerous. The manufacturer cannot be held liable for damage or injury caused by improper use of the table.
- Instruct others (particularly children) of any potential source of danger, especially when folding and unfolding the table. We recommend this is done by adults.
- The table tennis table should only be moved in the transport position as otherwise may cause injury.
- Depending on frequency of use, check all screws, bolts etc. regularly to ensure that they are in good condition.
- Caution: while assembling the product, keep out of the reach of children (choking hazard – contains small parts)
- For any further information, please contact your KNIGHT dealer.
- Do not use the table tennis table until it has been fully and correctly assembled and checked.
- Do not use corrosive or abrasive materials to clean the equipment. In most cases, a very slightly moist cloth is sufficient. There are specialist cleaning sprays available from most good retailers.

www.knightablesport.co.uk

Email: sales@knightablesport.co.uk